

QTY.	PART NUMBER	QTY.	PART NUMBER	QTY.	PART NUMBER	QTY.	PART NUMBER
1	CLAYTON-UF-1-01-LH SIDE BEAM	1	CLAYTON-BR-3-01-BOILER SHELL	1	CLAYTON-RG-5-01-LH-CRANKCASE SIDE	1	CLAYTON-MP-6-31-CRANKSHAFT CHAIN SPROCKET
1	CLAYTON-UF-1-02-RH SIDE BEAM	1	CLAYTON-BR-3-02-BOILER FOUNDATION RING	1	CLAYTON-RG-5-02-RH-CRANKCASE SIDE	1	CLAYTON-MP-6-32-LUBRICATOR CRANK RING
1	CLAYTON-UF-1-03-FRONT CROSS BEAM	1	CLAYTON-BR-3-03-BOILER FIRE BOX	2	CLAYTON-RG-5-03-CRANKSHAFT BEARING HOUSING	1	CLAYTON-MP-6-33-LUBRICATOR CRANK PIN
2	CLAYTON-UF-1-04-CROSS BEAM-1	1	CLAYTON-BR-3-04-BOILER CLINKERING	2	CLAYTON-RG-5-04-CRANKSHAFT BEARING	1	CLAYTON-MP-6-34-REVERSER ENGINE CRANK
1	CLAYTON-UF-1-05-CROSS BEAM-2	5	CLAYTON-BR-3-05-BOILER BUSH TYPE-A	2	CLAYTON-RG-5-05-CRANKSHAFT BEARING CAP	1	CLAYTON-MP-6-35-REVERSER LINK ROD
1	CLAYTON-UF-1-05-CROSS BEAM-2	3	CLAYTON-BR-3-06-BOILER BUSH TYPE-B	1	CLAYTON-RG-5-06-CRANKCASE OIL FILLER BOSS	2	CLAYTON-MP-6-36-REVERSER LINK ROD END
1	CLAYTON-UF-1-06-CROSS BEAM-2 LH-MOUNTING BRACKET	4	CLAYTON-BR-3-07-BOILER MOUNTING BRACKET	1	CLAYTON-RG-5-07-CRANKCASE OIL FILLER CAP	1	CLAYTON-MP-6-37A-LUBRICATOR CRANK ARM ROD
1	CLAYTON-UF-1-07-CROSS BEAM-2 RH-MOUNTING BRACKET	1	CLAYTON-BR-3-08-BOILER DOOR HINGE BRACKET	1	CLAYTON-RG-5-08-CRANKCASE FRONT	1	CLAYTON-MP-6-37B-LUBRICATOR CRANK ARM ROD END-1
1	CLAYTON-UF-1-08-FRONT BEAM ANGLE	1	CLAYTON-BR-3-09-BOILER CLINKER DOOR	1	CLAYTON-RG-5-09-CRANKCASE BOLTING FLANGE	1	CLAYTON-MP-6-37C-LUBRICATOR CRANK ARM ROD END-2
2	CLAYTON-UF-1-09-MID BEAM SUPPORT ANGLE	1	CLAYTON-BR-3-10-BOILER CLINKER DOOR HINGE	1	CLAYTON-RG-5-10-CRANKCASE TOP COVER-1	1	CLAYTON-MP-6-38-LUBRICATOR ARM PIN
8	CLAYTON-UF-1-10-GUSSET PLATE	1	CLAYTON-BR-3-11-BPOILER CLINKER DOOR LATCH ARM	1	CLAYTON-RG-5-11-CRANKCASE TOP COVER-2	1	CLAYTON-MP-6-39A-DRIVING CHAIN PATTERN
1	CLAYTON-UF-1-11-LH-FRONT LEAF SPRING BRACKET	1	CLAYTON-BR-3-12-BOILER CLINKER DOOR MOUNTING PLATE	1	CLAYTON-RG-5-12-CRANKCASE BOTTOM COVER	25	CLAYTON-MP-6-39B-DRIVING CHAIN INNER LINK
1	CLAYTON-UF-1-12-RH-FRONT LEAF SPRING BRACKET	1	CLAYTON-BR-3-13-BOILER CLINKER DOOR LATCH	1	CLAYTON-RG-5-13-SUMP BOLTING FLANGE	24	CLAYTON-MP-6-39C-DRIVING CHAIN OUTER LINK
2	CLAYTON-UF-1-13-FRONT LEAF SPRING BRACKET-2	1	CLAYTON-BR-3-14-BOILER BOTTOM TUBE PLATE	1	CLAYTON-RG-5-14-SUMP SIDE PLATE	10	CLAYTON-MP-6-39D-DRIVING CHAIN INNER LINK-1
4	CLAYTON-UF-1-14-FRONT LEAF SPRING HANGER BRACKET	1	CLAYTON-BR-3-15-BOILER TOP TUBE PLATE	2	CLAYTON-RG-5-15-SUMP PAN	11	CLAYTON-MP-6-39E-DRIVING CHAIN OUTER LINK-1
2	CLAYTON-UF-1-15-FRONT LEAF SPRING HANGER BRACKET UPPER SPACER	35	CLAYTON-BR-3-16-BOILER TUBE	1	CLAYTON-RG-5-16-CRANKCASE TOP BEARER	QTY.	PART NUMBER
4	CLAYTON-UF-1-16-FRONT LEAF SPRING EYE	1	CLAYTON-BR-3-17-BOILER CENTER TUBE	1	CLAYTON-RG-5-17-SUMP OIL DRAIN BUSH	1	CLAYTON-DC-7-01-CABIN FRAME WORK
12	CLAYTON-UF-1-17-FRONT LEAF SPRING BOLT	1	CLAYTON-BR-3-18-BOILER SMOKE BOX RING	1	CLAYTON-RG-5-18-SUMP OIL DRAIN PLUG	1	CLAYTON-DC-7-02-FRONT PLATE
2	CLAYTON-UF-1-18-FRONT LEAF SPRING	1	CLAYTON-BR-3-19-BOILER SMOKE BOX COVER	1	CLAYTON-RG-5-19-DRIVEN GEAR BUSH	1	CLAYTON-DC-7-03-BACK COVER
2	CLAYTON-UF-1-19-FRONT AXLE JAW	1	CLAYTON-BR-3-20-BOILER CHIMNEY BASE	1	CLAYTON-RG-5-20-RH-TRUNK GUIDE	1	CLAYTON-DC-7-04-LH- SIDE PLATE
4	CLAYTON-UF-1-20-KING PIN BUSH	1	CLAYTON-BR-3-22-BOILER SMOKE BOX CENTER TUBE	1	CLAYTON-RG-5-21-LH-TRUNK GUIDE	1	CLAYTON-DC-7-05-RH- SIDE PLATE
1	CLAYTON-UF-1-21-FRONT AXLE	1	CLAYTON-BR-3-23-BOILER SUPER HEATER OFF TAKE BUSH	1	CLAYTON-RG-5-22-CYLINDER BLOCK	2	CLAYTON-DC-7-06-DOOR
8	CLAYTON-UF-1-22-AXLE JAW STUD	1	CLAYTON-BR-3-24-BOILER MAIN STEAM OFF TAKE	1	CLAYTON-RG-5-24-CYLINDER BLOCK RH-FRONT COVER	1	CLAYTON-DC-7-07-RH-SEATING
2	CLAYTON-UF-1-23-LEAF SPRING PRESSURE PLATE	1	CLAYTON-BR-3-25-BOILER MANIFOLD STAND PIPE	1	CLAYTON-RG-5-25-CYLINDER BLOCK LH-FRONT COVER	1	CLAYTON-DC-7-08-LH-SEATING
2	CLAYTON-UF-1-24-REAR LEAF SPRING BRACKET-1	1	CLAYTON-BR-3-26-BOILER SUPER HEATER COIL PIPE	1	CLAYTON-RG-5-26-CYLINDER BLOCK RH-REAR COVER	1	CLAYTON-DC-7-09-COAL BUNKER LINING
2	CLAYTON-UF-1-25-REAR LEAF SPRING BRACKET-2	1	CLAYTON-BR-3-27-BOILER SUPER HEATER COIL PIPE PART-2	1	CLAYTON-RG-5-27-CYLINDER BLOCK LH-REAR COVER	1	CLAYTON-DC-7-10-CABIN ROOF FRAMING
2	CLAYTON-UF-1-26-REAR LEAF SPRING	1	CLAYTON-BR-3-28A-BOILER REGULATOR BASE	2	CLAYTON-RG-5-28-REAR CYLINDER COVER PISTON ROD GLAND	1	CLAYTON-DC-7-11-CABIN ROOF
2	CLAYTON-UF-1-27-REAR AXLE BOX	1	CLAYTON-BR-3-28B-BOILER REGULATOR TOP	2	CLAYTON-RG-5-29-PISTON ROD GLAND SEAL	1	CLAYTON-DC-7-12-CABIN FRAME EXTERNAL ROOF WOOD WORK
8	CLAYTON-UF-1-28-REAR AXLE BOX BEARING	1	CLAYTON-BR-3-28C-BOILER REGULATOR FRONT END	1	CLAYTON-RG-5-30-STEAM CHEST	QTY.	PART NUMBER
8	CLAYTON-UF-1-29-REAR AXLE BOX STUD	1	CLAYTON-BR-3-28D-BOILER REGULATOR VALVE SPINDLE	1	CLAYTON-RG-5-31-STEAM CHEST COVER PLATE	2	CLAYTON-TLR-8-01-TRAILER SIDE BEAM
2	CLAYTON-UF-1-30-REAR LEAF SPRING PRESSURE PLATE	1	CLAYTON-BR-3-28E-BOILER REGULATOR TOP NUT	4	CLAYTON-RG-5-32-STEAM CHEST VALVE SPINDLE GLAND	1	CLAYTON-TLR-8-02-TRAILER FRONT BEAM
2	CLAYTON-UF-1-31-RADIUS ROD END-1	1	CLAYTON-BR-3-28F-BOILER REGULATOR TOP SEAL	4	CLAYTON-RG-5-33-VALVE SPINDLE GLAND SEA	3	CLAYTON-TLR-8-03-TRAILER REAR AND CROSS BEAM
2	CLAYTON-UF-1-32-RADIUS ROD END-2	1	CLAYTON-BR-3-28G-BOILER REGULATOR HANDLE	2	CLAYTON-RG-5-34-VALVE SPINDLE GUIDE	1	CLAYTON-TLR-8-03-TRAILER REAR AND CROSS BEAM
2	CLAYTON-UF-1-33-RADIUS ROD	1	CLAYTON-BR-3-28H-BOILER REGULATOR PIPE CONNECTOR NUT	1	CLAYTON-RG-5-35-IDLER SHAFT	1	CLAYTON-TLR-8-03-TRAILER REAR AND CROSS BEAM
2	CLAYTON-UF-1-34-RADIUS AXLE BOX BOLT	1	CLAYTON-BR-3-29-BOILER CHIMNEY	1	CLAYTON-RG-5-36-EXHAUST FITTING	4	CLAYTON-TLR-8-04-TRAILER FRONT GUSSET PLATE
1	CLAYTON-UF-1-35-CABIN FDLOOR PLATE	1	CLAYTON-BR-3-30-BOILER CHIMNEY CROWN	1	CLAYTON-RG-5-37-INLET STEAM PIPE CONNECTION	4	CLAYTON-TLR-8-05-TRAILER REAR GUSSET PLATE
1	CLAYTON-UF-1-36A-FEEDWATER HEATER BASE	1	CLAYTON-BR-3-31-BOILER SMOKE BOX COVER LID	1	CLAYTON-RG-5-38-EXHAUST STEAM PIPE CONNECTION	12	CLAYTON-TLR-8-06-TRAILER CROSS BEAM GUSSET PLATE
1	CLAYTON-UF-1-36B-FEEDWATER HEATER BARREL	1	CLAYTON-BR-3-32A-BOILER WATER GAUGE TOP BODY	1	CLAYTON-RG-5-39-LH-CRANKSHAFT BEARING COVER	9	CLAYTON-TLR-8-07-TRAILER MAIN CROSS BEARER
1	CLAYTON-UF-1-36C-FEEDWATER HEATER TOP FLANGE	2	CLAYTON-BR-3-32B-BOILER WATER GAUGE NUT	1	CLAYTON-RG-5-40-RH-CRANKSHAFT BEARING COVER	2	CLAYTON-TLR-8-08-TRAILER LEAF SPRING FRONT BRACKET
1	CLAYTON-UF-1-36D-FEEDWATER HEATER TOP COVER	2	CLAYTON-BR-3-32C-BOILER WATER GAUGE SEAL	1	CLAYTON-RG-5-41-LH-SLIDE FULCRUM PIN BUSH	2	CLAYTON-TLR-8-09-TRAILER LEAF SPRING REAR BRACKET
1	CLAYTON-UF-1-36E-FEEDWATER HEATER BOILER FEED CONNECTOR	1	CLAYTON-BR-3-32D-BOILER WATER GAUGE GLASS TUBE	1	CLAYTON-RG-5-42-RH-SLIDE FULCRUM PIN BUSH	2	CLAYTON-TLR-8-10-TRAILER LEAF SPRING HANGER BRACKET UPPER SPACER
1	CLAYTON-UF-1-36F-FEEDWATER HEATER COIL	1	CLAYTON-BR-3-32E-BOILER WATER GAUGE BOTTOM BODY	1	CLAYTON-RG-5-43-SLIDE FULCRUM PIN BUSH O-RING	4	CLAYTON-TLR-8-11-TRAILER LEAF SPRING HANGER BRACKET
1	CLAYTON-UF-1-36G-FEEDWATER HEATER EXHAUST STEAM NIPPLE	1	CLAYTON-BR-3-32F-BOILER WATER GAUGE SPINDLE	1	CLAYTON-RG-5-44-RH-SLIDE FULCRUM PIN BUSH COVER	2	CLAYTON-TLR-8-12-TRAILER LEAF SPRING
1	CLAYTON-UF-1-36H-FEEDWATER HEATER FEEDWATER NIPPLE	1	CLAYTON-BR-3-32G-BOILER WATER GAUGE SPINDLE NUT	1	CLAYTON-RG-5-45A-OIL CHECK VALVE BODY	1	CLAYTON-TLR-8-13-TRAILER REAR AXLE
1	CLAYTON-UF-1-37-FRONT DRAWBAR	1	CLAYTON-BR-3-32H-BOILER WATER GAUGE TOP STOP SCREW	1	CLAYTON-RG-5-45B-OIL CHECK VALVE SCREW NIPPLE	4	CLAYTON-TLR-8-14-TRAILER LEAF SPRING U-BOLT
1	CLAYTON-UF-1-38A-REVERSER ANGLE MOUNTING BRACKET	1	CLAYTON-BR-3-32I-BOILER WATER GAUGE SPINDLE HANDLE	1	CLAYTON-RG-5-45C-OIL CHECK VALVE TUBE	2	CLAYTON-TLR-8-15-TRAILER LEAF SPRING PRESSURE PLATE
1	CLAYTON-UF-1-38B-REVERSER QUADRANT	2	CLAYTON-BR-3-33A-BOILER FEED CLACK BODY	1	CLAYTON-RG-5-45D-OIL CHECK VALVE PRESSURE SPRING	2	CLAYTON-TLR-8-16-TRAILER WHEEL
1	CLAYTON-UF-1-38C-REVERSER QUADRANT ARM KEEPER	2	CLAYTON-BR-3-33B-BOILER FEED CLACK STOP SCREW	1	CLAYTON-RG-5-45E-OIL CHECK VALVE BALL VALVE	2	CLAYTON-TLR-8-17-TRAILER WHEEL TYRE
2	CLAYTON-UF-1-38D-REVERSER QUADRANT SPACER	2	CLAYTON-BR-3-33C-BOILER FEED CLACK BALL VALVE	1	CLAYTON-RG-5-46A-LUBRICATOR ENCLOSURE	2	CLAYTON-TLR-8-18-TRAILER COUPLING MOUNTING BAR
1	CLAYTON-UF-1-38E-REVERSER ARM	1	CLAYTON-BR-3-34A-BOILER BLOWDOWN VALVE BODY	1	CLAYTON-RG-5-46B-LUBRICATOR BOTTOM SCREW BUSH	1	CLAYTON-TLR-8-19-TRAILER BALL COUPLING
1	CLAYTON-UF-1-38F-REVERSER ARM LATCH LEVER	1	CLAYTON-BR-3-34B-BOILER BLOWDOWN VALVE SCREW	1	CLAYTON-RG-5-46C-LUBRICATOR CYLINDER AND PRESSURE CHAMBER	1	CLAYTON-TLR-8-20-TRAILER COUPLING KEEPER PLATE
1	CLAYTON-UF-1-38G-REVERSER ARM LATCH	1	CLAYTON-BR-3-35A-BOILER SAFETY VALVE BODY	1	CLAYTON-RG-5-46D-LUBRICATOR RAM SEAL	2	CLAYTON-TLR-8-21-TRAILER COUPLING KEEPER PLATE SCREW
1	CLAYTON-UF-1-38H-REVERSER ARM LATCH RETAINING STRAP	2	CLAYTON-BR-3-35B-BOILER SAFETY VALVE BALL VALVE	1	CLAYTON-RG-5-46E-LUBRICATOR RAM SEAL NUT	1	CLAYTON-TLR-8-22-TRAILER RELEASE BAR
1	CLAYTON-UF-1-38I-REVERSER MAIN SHAFT	2	CLAYTON-BR-3-35C-BOILER SAFETY VALVE SPRING GUIDE	1	CLAYTON-RG-5-46F-LUBRICATOR BALL VALVE	1	CLAYTON-TLR-8-23-TRAILER RELEASE BAR HANDLE
1	CLAYTON-UF-1-38J-REVERSER PLUMBERING ARM	2	CLAYTON-BR-3-35D-BOILER SAFETY VALVE ADJUSTER PLATE	1	CLAYTON-RG-5-46G-LUBRICATOR PLUNGER	1	CLAYTON-TLR-8-24-TRAILER RELEASE BAR SPRING
1	CLAYTON-UF-1-38K-REVERSER FLANGER BLOCK	2	CLAYTON-BR-3-35E-BOILER SAFETY VALVE SPRING	1	CLAYTON-RG-5-46H-LUBRICATOR PRESSURE SPRING	1	CLAYTON-TLR-8-25-TRAILER LOADER FLOOR
1	CLAYTON-UF-1-39A-WATER TANK INNER FRAME	2	CLAYTON-BR-3-35F-BOILER SAFETY VALVE TOP COVER	1	CLAYTON-RG-5-46I-LUBRICATOR BOTTOM SPRING RETAINER SCREW	2	CLAYTON-TLR-8-26A-TRAILER LOADER TOP AND BOTTOM FRAME WORK
1	CLAYTON-UF-1-39B-WATER TANK SIDE COVER	1	CLAYTON-BR-3-35G-BOILER SAFETY VALVE PLUG	1	CLAYTON-RG-5-46J-LUBRICATOR RAM	2	CLAYTON-TLR-8-26B-TRAILER LOADER BOTTOM FRAME WORK OUTER ANGLE TYPE-1
1	CLAYTON-UF-1-39C-WATER TANK TOP COVER	1	CLAYTON-BR-3-35H-BOILER SAFETY VALVE NIPPLE	1	CLAYTON-RG-5-46K-LUBRICATOR RAM PRESSURE SPRING	2	CLAYTON-TLR-8-26C-TRAILER LOADER BOTTOM FRAME WORK OUTER ANGLE TYPE-2
1	CLAYTON-UF-1-39D-WATER TANK BOTTOM COVER	1	CLAYTON-BR-3-36A-BOILER WHISTLE VALVE BODY	1	CLAYTON-RG-5-46L-LUBRICATOR ECCENTRIC	8	CLAYTON-TLR-8-26D-TRAILER LOADER INNER AND OUTER FLAT STRAP
1	CLAYTON-UF-1-39E-WATER TANK FRONT AND BACK COVER	1	CLAYTON-BR-3-36B-BOILER WHISTLE VALVE BALL VALVE	1	CLAYTON-RG-5-46M-LUBRICATOR ECCENTRIC SHAFT	2	CLAYTON-TLR-8-26E-TRAILER LOADER BOTTOM FRAME WORK OUTER ANGLE TYPE-3
1	CLAYTON-UF-1-39F-WATER TANK FILLER LID	1	CLAYTON-BR-3-36C-BOILER WHISTLE VALVE SPRING	1	CLAYTON-RG-5-46N-LUBRICATOIR ECCENTRIC SHAFT BUSH	2	CLAYTON-TLR-8-26F-TRAILER LOADER BOTTOM FRAME WORK INNER ANGLE TYPE-1
1	CLAYTON-UF-1-39G-WATER TANK MAN HOLE COVER	1	CLAYTON-BR-3-36D-BOILER WHISTLE VALVE SPRING NUT	1	CLAYTON-RG-5-46O-LUBRICATOIR SWING ARM	2	CLAYTON-TLR-8-26G-TRAILER LOADER BOTTOM FRAME WORK INNER ANGLE TYPE-2
1	CLAYTON-UF-1-39G-WATER TANK MAN HOLE COVER	1	CLAYTON-BR-3-36E-BOILER WHISTLE VALVE PUSH ROD	1	CLAYTON-RG-5-46P-LUBRICATOIR RACHET	2	CLAYTON-TLR-8-26I-TRAILER LOADER BOTTOM FRAME WORK INNER ANGLE TYPE-3
3	CLAYTON-UF-1-39h-WATER TANK BUSH	1	CLAYTON-BR-3-37-BOILER MANIFOLD	1	CLAYTON-RG-5-46Q-LUBRICATOIR PAWL-1	1	CLAYTON-TLR-8-27-TRAILER LOADER PLANKING
2	CLAYTON-UF-1-39I-WATER TANK HARDWOOD BEARER	1	CLAYTON-BR-3-38A-BOILER BLOWER VALVE BODY	1	CLAYTON-RG-5-46R-LUBRICATOIR PAWL-2	4	CLAYTON-TLR-8-29A-TRAILER LOADER OUTER GUSSET TYPE-1
1	CLAYTON-UF-1-39J-WATER TANK INJECTOR SUPPLY FITTING	1	CLAYTON-BR-3-38B-BOILER BLOWER VALVE SPINDLE GUIDE NUT	1	CLAYTON-RG-5-46S-LUBRICATOIR PAWL-1 SHAFT	4	CLAYTON-TLR-8-29B-TRAILER LOADER INNER GUSSET TYPE-1
2	CLAYTON-UF-1-39K-WATER TANK ANGLE STRAP	1	CLAYTON-BR-3-38C-BOILER BLOWER VALVE SPINDLE NUT	1	CLAYTON-RG-5-46T-LUBRICATOIR PAWL-2 SHAFT	16	CLAYTON-TLR-8-30A-TRAILER LOADER INNER AND OUTER GUSSET TYPE-2
4	CLAYTON-UF-1-39L-WATER TANK TIE ROD	1	CLAYTON-BR-3-38D-BOILER BLOWER VALVE SEAL	1	CLAYTON-RG-5-46U-LUBRICATOIR PAWL-1 SPRING	4	CLAYTON-TLR-8-31A-TRAILER LOADER OUTER GUSSET TYPE-2
1	CLAYTON-UF-1-40-BALL HITCH MOUNTING PLATE	1	CLAYTON-BR-3-38E-BOILER BLOWER VALVE SPINDLE	1	CLAYTON-RG-5-46V-LUBRICATOIR PAWL-2 SPRING	4	CLAYTON-TLR-8-31B-TRAILER LOADER INNER GUSSET TYPE-2
1	CLAYTON-UF-1-41-BALL HITCH	1	CLAYTON-BR-3-38F-BOILER BLOWER VALVE SPINDLE HAND WHEEL	QTY.	PART NUMBER	4	CLAYTON-TLR-8-32A-TRAILER LOADER OUTER GUSSET TYPE-3
1	CLAYTON-UF-1-42-RH-FRONT MUDGUARD	1	CLAYTON-BR-3-39A-BOILER INJECTOR STEAM VALVE BODY	1	CLAYTON-MP-6-01A-RH-CRANKSHAFT SHAFT	4	CLAYTON-TLR-8-32B-TRAILER LOADER INNER GUSSET TYPE-3
1	CLAYTON-UF-1-43-LH-FRONT MUDGUARD	1	CLAYTON-BR-3-39B-BOILER INJECTOR STEAM VALVE SINDLE GUIDE NUT	1	CLAYTON-MP-6-01B-LH-CRANKSHAFT SHAFT	2	CLAYTON-TLR-8-34-TRAILER AXLE END COLLAR
1	CLAYTON-UF-1-44-RH-REAR MUD GUARD	1	CLAYTON-BR-3-39C-BOILER INJECTOR STEAM VALVE SPINDLE NUT	1	CLAYTON-MP-6-01C-MIDDLE-CRANKSHAFT SHAFT	2	CLAYTON-TLR-8-35- AXLE HUB CAP
1	CLAYTON-UF-1-45-LH-REAR MUD GUARD	1	CLAYTON-BR-3-39D-BOILER INJECTOR STEAM VALVE SEAL	2	CLAYTON-MP-6-01D-CRANKSHAFT CON ROD SHAFT		
1	CLAYTON-UF-1-46A-INJECTOR WATER VALVE BODY	1	CLAYTON-BR-3-39E-BOILER INJECTOR STEAM VALVE SPINDLE	4	CLAYTON-MP-6-01E-CRANKSHAFT CRANK CHEEK		
1	CLAYTON-UF-1-46B-INJECTOR WATER VALVE BODY SPINDLE PLATE	1	CLAYTON-BR-3-39F-BOILER INJECTOR STEAM VALVE SPINDLE HAND WHEEL	2	CLAYTON-MP-6-02-VALVE SPINDLE		
1	CLAYTON-UF-1-46C-INJECTOR WATER SPINDLE	1	CLAYTON-BR-3-40A-BOILER FEED CLACK-BYPASS BODY	2	CLAYTON-MP-6-03-PISTON ROD		
1	CLAYTON-UF-1-46D-INJECTOR WATER VALVE SPINDLE NUT	1	CLAYTON-BR-3-40B-BOILER FEED CLACK-BYPASS BOILER CONNECTOR	2	CLAYTON-MP-6-04-PISTON		
1	CLAYTON-UF-1-46E-INJECTOR WATER VALVE SPINDLE SEAL	1	CLAYTON-BR-3-40C-BOILER FEED CLACK-BYPASS VALVE	2	CLAYTON-MP-6-05-SLIDE VALVE		
1	CLAYTON-UF-1-46F-INJECTOR WATER VALVE INLET NUT	1	CLAYTON-BR-3-40D-BOILER FEED CLACK-BYPASS SPINDLE GUIDE	2	CLAYTON-MP-6-06-VALVE BAR		
1	CLAYTON-UF-1-46G- INJECTOR WATER VALVE SPINDLE HAND WHEEL	1	CLAYTON-BR-3-40E-BOILER FEED CLACK-BYPASS STOP SCREW	2	CLAYTON-MP-6-07-VALVE SPINDLE CROSSHEAD		
QTY.	PART NUMBER	1	CLAYTON-BR-3-40F-BOILER FEED CLACK-BYPASS PLUG SCREW	2	CLAYTON-MP-6-08-PISTON ROD CROSSHEAD		
1	CLAYTON-SS-2-01-STEERING BOX MOUNTING PLATE	1	CLAYTON-BR-3-40G-BOILER FEED CLACK-BYPASS SPINDLE	2	CLAYTON-MP-6-09-GUDGEON PIN		
1	CLAYTON-SS-2-02-STEERING BOX	1	CLAYTON-BR-3-40H-BOILER FEED CLACK-BYPASS SPINDLE HANDLE	2	CLAYTON-MP-6-10-CONNECTING ROD		
1	CLAYTON-SS-2-03-STEERING BOX TOP INSERT	1	CLAYTON-BR-3-41-BOILER WHISTLE LEVER BRACKET	2	CLAYTON-MP-6-11-CONNECTING ROD STRAP		
1	CLAYTON-SS-2-04-STEERING BOX TOP BUSH	1	CLAYTON-BR-3-42-BOILER WHISTLE LEVER	2	CLAYTON-MP-6-12-CONNECTING ROD BIG END BRASSES		
1	CLAYTON-SS-2-05-STEERING NUT	1	CLAYTON-BR-3-43A-BOILER EXHAUST ELBOW	2	CLAYTON-MP-6-13-CONNECTING ROD JOY GEAR BUSH		
2	CLAYTON-SS-2-06-STEERING LIFTING ARM	1	CLAYTON-BR-3-43B-BOILER EXHAUST BLAST NOZZLE CONNECTOR	2	CLAYTON-MP-6-14-CONNECTING ROD SMALL END BUSH		
1	CLAYTON-SS-2-07-STEERING SPINDLE	1	CLAYTON-BR-3-43C-BOILER EXHAUST BLAST NOZZLE	1	CLAYTON-MP-6-15-CRANKSHAFT SPACER		
1	CLAYTON-SS-2-08-STEERING QUADRANT	1	CLAYTON-BR-3-44-BOILER GRATE	2	CLAYTON-MP-6-16-CORRECTING LINK		
2	CLAYTON-SS-2-09-FRONT WHEEL STUB AXLE	1	CLAYTON-BR-3-45-BOILER GRATE HINGE PLATE	2	CLAYTON-MP-6-17-ANCHOR LINK		
2	CLAYTON-SS-2-10-KING PIN	1	CLAYTON-BR-3-46-BOILER GRATE HINGE MOUNTING PLATE	4	CLAYTON-MP-6-18-VIBRATING LEVER		
1	CLAYTON-SS-2-11-RH-STEERING ARM	1	CLAYTON-BR-3-47-BOILER GRATE LATCH PIN	2	CLAYTON-MP-6-19-RADIUS ROD		
1	CLAYTON-SS-2-12-LH-STEERING ARM	1	CLAYTON-BR-3-48-BOILER ASHPAN	4	CLAYTON-MP-6-20-SLIDE		
1	CLAYTON-SS-2-14-STEERING WHEEL	1	CLAYTON-BR-3-49-BOILER ASHPAN HINGE BRACKET	1	CLAYTON-MP-6-21-LH-SLIDE FULCRUM PIN		
2	CLAYTON-SS-2-15-FRONT WHEEL	2	CLAYTON-BR-3-50-BOILER GRATE DUMP LEVER BRACKET	1	CLAYTON-MP-6-22-RH-SLIDE FULCRUM PIN		
2	CLAYTON-SS-2-16-TYRE	1	CLAYTON-BR-3-51-BOILER GRATE DUMP LEVER	4	CLAYTON-MP-6-23-DIE BLOCK		
2	CLAYTON-SS-2-17-FRONT WHEEL BUSH	1	CLAYTON-BR-3-52-BOILER ASHPAN DAMPER BRACKET	1	CLAYTON-MP-6-24-SLIDE SHAFT		
1	CLAYTON-SS-2-18-TRACK ROD	1	CLAYTON-BR-3-53-BOILER ASHPAN DAMPER ADJUSTER AND ROD	4	CLAYTON-MP-6-25-VIBRATING LEVER PIN		
3	CLAYTON-SS-2-19-TRACK ROD END	1	CLAYTON-BR-3-54-BOILER ASHPAN DAMPER ADJUSTER POSITION HOLDING LATCH	1	CLAYTON-MP-6-26-ANCHOR LINK SHAFT		
1	CLAYTON-SS-2-20-DRAG LINK END	1	CLAYTON-BR-3-55-BOILEREXHAUST PIPE CONNECTION FLANGE	1	CLAYTON-MP-6-27-WATER PUMP DRIVER GEAR		
1	CLAYTON-SS-2-21-DRAG LINK ROD	QTY.	PART NUMBER	1	CLAYTON-MP-6-28-WATER PUMP IDLER GEAR		
1	CLAYTON-SS-2-22-STEERING QUADRANT TOP BOLT	1	CLAYTON-RG-4-01-REAR AXLE	1	CLAYTON-MP-6-29-WATER PUMP DRIVEN GEAR		
1	CLAYTON-SS-2-23-STEERING QUADRANT CENTER BOLT	4	CLAYTON-RG-4-02-REAR AXLE CHAIN SPROCKET	1	CLAYTON-MP-6-30A-WATER PUMP BODY		
1	CLAYTON-SS-2-24-						